


HOW TO SET UP A FUEL ALERT IN LIVELINK

You can now set up alerts in LiveLink which will email or text you if a machines' fuel level suddenly starts dropping.

It's easy to set up using the following instructions:




Go to LiveLink Classic (JCBLL.com) and sign in

Go to top left menu (3 horizontal bars)

Select Admin

Under Communication Profiles...

Select 'Add new communication profile'



Starting at the top, give the Alert a Name and a Description

Under Business Events, find 'Excessive Fuel Loss' and 'Fuel Level Dropped'; select them so they turn blue

Click Add - this will move them to the Included column

Under Users, select the people who will receive the notifications and click Add

Under Machine Groups, select All and click Add

Click Save

Please note, this alert is currently only available for Backhoe Loaders and Tracked Excavators.